

UK and European Brake Setup Instructions for Frog City Bikes

The brakes of the City Bikes can be set up for both British and European specifications. This can be achieved by attaching the brake cables to the corresponding brake levers as required. **For the rear brake cable, the required cable routing differs depending on which specification the brakes are set up to.**

For the British standard (the front brake lever is on the right, and the rear brake lever is on the left), the rear brake cable should route along the left side of the head tube (see images for UK Specification below).

British Brake Setup



For the European brake setup (i.e., right brake lever is connected with the rear brake), the cable needs to be routed along the right hand side of the head tube (see images for European brake setup below).

European Brake Setup

